

PA 44 Seminole Preflight Checklist

INTERIOR	
Documents(ARROW)	Verify
Fuel Selectors.....	On
Trim.....	Set for Takeoff
Flaps.....	Full Down
Cowl Flaps.....	Open
Carb Heat.....	Off
Mixtures.....	Cutoff
Props.....	Full forward
Throttles.....	Close
Magneto/All switches.....	OFF
Blower Fan.....	Off (Center)
Heater.....	Off (Center)
Landing Gear Lever.....	Down
Landing Gear Emerg.	Secure
Pitot Static.....	Drain / Check
Battery Master.....	On
Landing gear lights.....	3 Green
Exterior lights.....	On / Check / Off
Pitot Heat.....	On / Check / Off
Fuel Gauges.....	Check Quantity
Annunciator Panel.....	Check
Heater Overheat light.....	Check
Battery Master.....	Off
Fire extinguish Check.....	Check in green

EXTERIOR	
NOTE: CHECK FOR LOOSE OR MISSING HARDWARE DURING EXTERIOR PREFLIGHT	
Fuel sumps.....	Drain
Right wing.....	Check
R Control Surfaces.....	Check
R Engine Nacelle.....	Check
R Fuel Qty.....	Check
R Oil Qty Check.....	Check
R Gear, Tire, Brakes.....	Check
Nose section.....	Check
Nose Gear & Tire.....	Check
L Engine Nacelle.....	Check
L Fuel Qty.....	Check
L Oil Qty.....	Check
Pitot mast.....	Check Clear
Left wing.....	Check
L Control Surfaces.....	Check
Left Fuselage.....	Check
Empennage.....	Check
Antennae.....	Check
Vertical Stabilizer.....	Check
Stabilator Check.....	Check
Right fuselage.....	Check
Baggage Door.....	Check Secure
Walk around.....	Check no debris

PA 44 Seminole Preflight Checklist

INTERIOR	
Documents(ARROW)	Verify
Fuel Selectors.....	On
Trim.....	Set for Takeoff
Flaps.....	Full Down
Cowl Flaps.....	Open
Carb Heat.....	Off
Mixtures.....	Cutoff
Props.....	Full forward
Throttles.....	Close
Magneto/All switches.....	OFF
Blower Fan.....	Off (Center)
Heater.....	Off (Center)
Landing Gear Lever.....	Down
Landing Gear Emerg.	Secure
Pitot Static.....	Drain / Check
Battery Master.....	On
Landing gear lights.....	3 Green
Exterior lights.....	On / Check / Off
Pitot Heat.....	On / Check / Off
Fuel Gauges.....	Check Quantity
Annunciator Panel.....	Check
Heater Overheat light.....	Check
Battery Master.....	Off
Fire extinguish Check.....	Check in green

EXTERIOR	
NOTE: CHECK FOR LOOSE OR MISSING HARDWARE DURING EXTERIOR PREFLIGHT	
Fuel sumps.....	Drain
Right wing.....	Check
R Control Surfaces.....	Check
R Engine Nacelle.....	Check
R Fuel Qty.....	Check
R Oil Qty Check.....	Check
R Gear, Tire, Brakes.....	Check
Nose section.....	Check
Nose Gear & Tire.....	Check
L Engine Nacelle.....	Check
L Fuel Qty.....	Check
L Oil Qty.....	Check
Pitot mast.....	Check Clear
Left wing.....	Check
L Control Surfaces.....	Check
Left Fuselage.....	Check
Empennage.....	Check
Antennae.....	Check
Vertical Stabilizer.....	Check
Stabilator Check.....	Check
Right fuselage.....	Check
Baggage Door.....	Check Secure
Walk around.....	Check no debris